



### Eurosnoeren.

Artikel	Uitvoering	Kleur	Lengte snoer
5030031	2 x 0,75 <sup>2</sup>	zwart	100 cm
0001035	2 x 0,75 <sup>2</sup>	wit	100 cm
0000390	2 x 0,75 <sup>2</sup>	zwart	200 cm
0000391	2 x 0,75 <sup>2</sup>	wit	200 cm
5030098	2 x 0,75 <sup>2</sup>	transparant	200 cm
5030034	2 x 0,75 <sup>2</sup>	goud	300 cm
0000392	2 x 0,75 <sup>2</sup>	zwart	300 cm
0001381	2 x 0,75 <sup>2</sup>	wit	300 cm
0000396	2 x 0,75 <sup>2</sup>	wit	300 cm inclusief aan/uit schakelaar
0001037	2 x 0,75 <sup>2</sup>	wit	400 cm